



This is intended for quick guide consultation only and does not replace the Use and Maintenance Manual. Before using the machine, read the Use and Maintenance Manual contained in the machine packaging thoroughly and rigorously respect all instructions.

Operation Instructions



1. Fill the solution tank



2. Insert key into switch and turn on



3. Lower the machine head by pressing the pedal downwards and to the left



4. Open the solution tank lever to the desired water flow




5. Press the brush button



6. Press the suction button



7. Lower the squeegee using the lever



8. Pull up on the drive lever to begin cleaning

9. When you have finished cleaning

- Turn the brush motor off
- Turn the suction motor off
- Raise the machine head
- Raise the squeegee
- Close the detergent tank tap
- Charge the batteries if needed

Troubleshooting

BRUSH MOTOR WILL NOT START

Select brush function
Ensure machine has clean water

MACHINE DOES NOT COME ON/START UP

Ensure batteries are connected and charged
Check fuse reset switches

MACHINE WILL NOT MOVE

Check for brush operation
Check battery voltage

MACHINE LEAVES FLOOR WET

Ensure recovery tank is not full
Check squeegee body/hose for blockage
Check squeegee blades for condition
Ensure that vacuum motor is turning on

MACHINE LEAVES FLOOR DIRTY

Check solution is being dispensed
Check correct brush/pad floor for floor type
Ensure head is completely lowered to floor

Maintenance



Empty dirty solution tank through drain hose



Clean the solution tank




Ensure suction filter is undamaged and clean



Ensure solution tank fill filter is undamaged and clean




Ensure solution filter is undamaged and clean



Remove and clean brushes



Ensure squeegee is clean and blades are not damaged



Check the battery charge. Charge if necessary.

Replacing Squeegee Blades

- Remove squeegee assembly from machine
- Loosen both outer yellow hand knobs fully
- Flip unit over
- Reuse the same blade, reversing the edge in contact with the floor until all 4 edges are worn, or replace with a new blade
- Flip unit over
- Tighten both outer yellow hand knobs fully
- Reinstall squeegee assembly on machine

Checking Fuses



Locate fuse panel under recovery tank. Open with Phillips screwdriver.



Control fuses on left. Strip fuse for brush operation on right.

- If either fuse is blown, please contact IPC or your local distributor to replace fuse assembly.

www.ipcworldwide.com/us/contacts
800-486-2775